

TrueNute Startup Kit Instruction Outline

Day 1

1. Add TrueNute Fake Fish to bring ammonia level in the system to 4 PPM.
2. Add First package of TrueNute Vegetative Growth Mix with Nitrate.
3. Add Micro-Nutrient Pack
4. You will check the ammonia level daily so that you can add more TrueNute Fake Fish as needed to maintain 4PPM until day 15.

Day 15

1. Add second package of TrueNute Vegetative Growth Mix.
2. You will check the ammonia level daily so that you can add more TrueNute Fake Fish as needed to maintain 2PPM.

Day 30

1. Add Third package of TrueNute Vegetative Growth Mix.
2. You will check the ammonia level daily so that you can add more TrueNute Fake Fish as needed to maintain 2PPM.